


Thomsen's Solution Mixing and Frequency Chart

	Thomsen's Heavy Duty Cleaner Solution	Thomsen's Cleaner / Conditioner Solution	mPerial Sanitizer for Thomsen's
Packaging	4 x 1 gallon	4 x 1 gallon	1 Gallon
Dispensing Process	1 oz. pump dispenser Green	1 oz. pump dispenser Blue	1 oz. pump dispenser Red
Mixing Instructions	Pump 3 oz. concentrate to 1-quart water in SVC Cleaning charging tray	Pump 3 oz. concentrate to 1-quart water in SVC Conditioner charging tray	1 oz. concentrate to 64 oz. of water in SVC Dilution jug, then pour 32 oz. of the mixed solution into the SVC disinfectant charging tray
Mixing Vessel	SVC Charging Tray	SVC Charging Tray	SVC 64-ounce dilution jug.
Mixed Solutions Application Quantity Per Cleaning Pad	6 oz. soaked	4 oz. soaked	3 oz. soaked
Mixed Solutions Application Quantity per escalator	12 oz. soaked	8 oz. soaked	6 oz. soaked
Minutes Cleaning Pad is Use (lower)	15 minutes	10 minutes	5 minutes
Cleaning Pad (Upper) for drying only	Yes	Yes	Yes
Frequency of Use	Initial Deep cleaning. Follow-up deep cleaning as necessary.	Daily/Weekly	Daily / Weekly
ATP RLU reading minimums	0 - 30	0 - 30	0 - 30

For Customer Support and Information Regarding Mixing and Frequency Call 866 729 2959 ext. 211